



OPERATION MANUAL

DSC 423/424 Demagnetizers

MAG-MATE™ GROUP Toll Free: 888.582.0822

WIRING INSTRUCTIONS:

- *For 115 VAC units, plug unit in to a grounded 115 VAC receptacle.
- *For 230 VAC units, connect green wire to the earth ground and the white and black wire to 230 VAC line (single phase).
- *Always wire units in accordance with local regulations.

GENERAL OPERATING INSTRUCTIONS:

- *Always keep the pieces to be demagnetized as close to the Demagnetizer face as possible.
- *Move the work piece slowly across the face of the Demagnetizer until it is out of the demagnetizing field. (Area of the black phenolic plastic)
- *Small items may require physical separation for satisfactory results.
- *On assemblies, it may be necessary to disassemble the components and pass them through the demagnetizing field individually.
- *Depending upon the material composition and design of the object to be demagnetized, it may be necessary to rotate the material from a longitudinal to a lateral axis for satisfactory results.

WARNING:

Keep Demagnetizer turned OFF when not in use to prevent excessive heating that could damage internal components and shorten life of Demagnetizer.

Persons wearing pacemakers should not operate this unit and should be kept clear of the area.

©2005 **INDUSTRIAL MAGNETICS, INC.**

1240 M-75 South • P.O. Box 80 • Boyne City, Michigan 49712-0080 • Phone: (231) 582-3100

Fax: (231) 582-0622 • Web: www.magnetics.com • E-mail: imi@magnetics.com

AUTOMATION 888-582-0823

MAG-MATE™ 888-582-0822

TRAMP METAL 888-582-0821